

Visual Merchandising (Creo™)

Applicable Products:

Plasma Brackets (CRPB)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Insert puck glides into bottom crossbar channel (fig. A-1). Slide puck glides to desired location (fig. A-2).
2. Hook video bracket over top crossbar (fig. B-1) and align bottom hole with puck glide on bottom crossbar (fig. B-2).
3. Screw puck onto puck glide to secure brackets (fig. C-1 & fig. C-2).
4. Screw TV unit onto brackets (fig. D).

