Communication Center SignHolder™ - LFPB Series

- 1. Slide the uprights of the frame structure over the stand-off sections of the base and fasten the uprights in place using the screws provided.
- 2. Slightlty loosen the nylon screws to create a gap for mounting the acrylic holders. Place the keyholes of the acrylic holder over the pair of nylon screws.
- 3. Slightly tighten the nylon screws to secure the acrylic holder.
- 4. Repeat steps 2 and 3 for the additional acylic holders (not shown).









