

Framegraphix SnapFrames

1. Place the joiners into the channels and tap together using a rubber mallet for a permanent press fit (Fig. A).
2. Use the attached eye hooks to hang.
3. Attach styrene backing by opening the SnapFrame and peeling the covers off adhesive siding (Fig. B).

Applicable Products:
FrameGraphix SnapFrames
Ceiling Hung

