

Signholders (SignPost System™)

Applicable Products:

SnapFrame (YEO, SN)

**NOTE: Most upright components must be installed before completing unit assembly.
End user determines component location.**

1. Align knob rest glides with the upright channel. Slide knob rest glides into upright channel and temporarily tighten.
2. Hook frame brackets over knob rests and tighten knobs to secure frame in place.
3. Repeat for opposite frame.
4. Place finishing cap on top of upright to complete unit installation.

NOTE: Frame shown below may look different from your model, but assembly instructions remain the same.

