

Perfex™ Standoff Kits

Applicable Products:

PXSO Standoff Kit

1. If mounting on drywall or hollow walls, determine frame location and pre-drill a 3/16" hole and insert Molly Anchors provided (not shown).
2. If mounting onto generic wall, determine frame location and screw the wall mount standoffs into the wall (fig. A-1).
3. Attach frame brackets onto the standoffs (fig. A-2 & A-3).
4. Place frame over the top and bottom mounting brackets (fig. B) and (fig. C).

