

# SwingWing SignFrame™ - WINGK Series

1. Attach the base to oval upright and round support tube using the flat head screws provided from below.
2. Attach the pair of round/pan head screws provided to the cell nut on the upright. Leave a small (~1/8) gap, do not fully tighten.
3. Slide the frame assembly down over the upright and engage the screws. Tighten the screws to secure the position.
4. Fasten the provided remaining flat head screw to the round support tube, through the lower plate.
5. Attach the cap.
6. Insert graphics.

