

# Lobby Easels

1. Insert sliding adjustable signholders onto top section - push up toward top and tighten to desired height. (Figure A).
2. Insert top section swedged poles into bottom base and push down to secure. (Figure B).
3. Adjust signholders to desired height if needed.

## Applicable Products:

414, 415

