

# Studio Artist Easel

Applicable Products:

600 Easel

1. Attach base to main upright using carriage bolts and wingnuts (fig. A).
1. Open back leg support and secure with wingnut (fig. B).
4. Attach metal feet to frame holder and utility tray (fig. C-1), then slide into support channel and tighten (fig. C-2).
3. Rotate palette holders if needed (fig. D).

